
# SmartCell

Wireless Remote Indicator

Installation Guide



SC-62-0210-0001-99 model shown

## 1 Pre installation

Installation must conform to applicable local installation codes and should only be installed by a fully trained competent person.



The use of a non-metallic spacer should be considered if mounting the device on to a metal surface.




This device contains electronics that may be susceptible to damage from Electrostatic Discharge (ESD). Take appropriate precautions when handling electronic boards.



To ensure correct operation, products must be used within the specified environmental operating conditions.


#### **3 Remove mounting plate**

 Remove the mounting plate by turning the device ANTICLOCKWISE, to release it from the mounting plate.



#### 5 Fit batteries

When fitting / replacing batteries, observe correct polarity, using only specified batteries.



#### ©2021 EMS Ltd. All rights reserved.

Part number


SC-62-0211-0001-99

SC-62-0210-0001-99

Product description

SmartCell Wireless Remote Indicator


SmartCell Wireless Remote Indicator (Fire Detection Indicator Text)



### 4 Fix mounting plate


When fixing to the wall, all four fixing positions should be used to ensure a firm fixing.


- Where existing electrical mounting boxes are present, two fixing positions may be used.
- Use suitable fasteners and fixings.
- Observe the orientation marking!



#### 6 Configuration

The device must now be added (programmed) to the control panel.





#### Specification


Operating temperature	-10 to +55 °C
Storage temperature With batteries Without batteries	-10 to +30 °C -10 to +55 °C
Humidity	0 to 95% noncondensing
Location	Type A: for indoor use
IP rating	IP21C
Supply	3 x ER14505M 3.6 V lithium thionyl chloride batteries (Fanso or Titus)
CAUTION!	

- This is a life safety product. Only use manufacturer approved battery types.
  Failure to do so may result in damage to the product.
- DO NOT mix batteries of different type or age.
- When replacing batteries; remove all old batteries before fitting replacements.

Operating voltage	2.7 to 3.65 VDC
Current consumption	0.1 to 400 mA
Power consumption	1.46 W max.
Operating frequency	868 MHz
Output transmitter power	14 dBm / 25 mW
Signalling protocol	X5
Dimensions (Ø x D)	110 x 39 mm

# 8 Completing the installation

Reassemble the device as shown below.



# 

- The device should be tested upon installation, in accordance with local requirements.
- Testing should only be carried out by a fully trained competent person.

### **Regulatory** information

Manufacturer	Carrier Manufacturing Polska Sp. Z o.o. Ul. Kolejowa 24. 39-100 Ropczyce, Poland
Year of manufacture	See devices serial number label
Certification	€21
Certification body	0905
CPR DoP	0359-CPR-202116
Approved to	EN54-13:2005. Fire detection and fire alarm systems. Part 13: compatibility assessment of system components.
	EN54-25:2008. Incorporating corrigenda september 2010 and march 2012. Fire detection and fire alarm systems. Part 25: components using radio links.
European Union directives	EMS declares that the radio equipment type SmartCell Wireless Remote Indicator is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.mysmartcell.com
	2012/19/EC (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see www.recyclethis.info Dispose of your batteries in an environmentally friendly manner according to your local regulations.